

Study of noisy pixel appearance and thermal neutron fluxes with Timepix3 in ATLAS

C. Lesmes, B. Bergmann, T. Billoud, P. Broulim, P. Burian, C. Leroy, P. Manek, L. Meduna, S. Pospisil, A. Sopczak, M. Suk

Institute of Experimental and Applied Physics
Czech Technical University in Prague

July 8, 2019



1. Introduction

1.1 ATLAS Timepix3 devices

1.2 Motivation

2. Noisy pixel removal

2.1 Method

2.2 Results

2.3 Improvement

3. Thermal Neutrons

4. From clusters to luminosity

5. Luminosity curve

5.1 Model

5.2 Fitted luminosity curve

6. Conclusions

Introduction



ATLAS MPX and TPX networks were used to:

- ▶ Measure radiation field at different positions in ATLAS and use the results for ATLAS simulation validation.
- ▶ Measure the activation of material during and after collisions.
- ▶ Measure ATLAS luminosity.

In this presentation we use the newly installed (before end of Run-2) Timepix3 devices in ATLAS to study their capability for improved luminosity determination.

ATLAS Timepix3 features:

- ▶ Stack of two independent silicon detectors (I4 and J4).
- ▶ Time binning of 1.56 ns.
- ▶ 256 x 256 independent pixels.
- ▶ Simultaneous measurement of time and energy.
- ▶ Continuous readout.
- ▶ Synchronization with LHC clock.




Figure: Timepix3 devices

Introduction - ATLAS Timepix3 devices




Figure: Location of TPX and Timepix3 devices in ATLAS

- ▶ TPX3-1 used for analysis located 4.6 m away from interaction point.

Introduction - ATLAS Motivation



Problem 1: Appearance of random noisy pixels creating count rates not following a standard luminosity curve.




Figure: Time history of Timepix3 cluster count for LHC fill 6677

- Conduct a noisy pixel analysis to find them and remove them.

Introduction - ATLAS Motivation



Problem 2: Activation of surrounding material can create a background signal which adds a systematic uncertainty to the luminosity measurement.




Figure: Cluster count contribution to the signal


- Mitigate the problem by using only the thermal neutron count rate.

Noisy pixel removal


For the implementation of the noisy pixel removal we must understand the following:

- ▶ A pixel is considered noisy if its count rate is 5 standard deviations away from the mean count rate of all pixels.
- ▶ The borders of the detector are more prone to noise so they are removed from the analysis.
- ▶ Detector I4 had a LiF cover for thermal neutron identification. To account for the different statistics below the converter, the removal was done separately for this region.
- ▶ The configuration matrix of the detector resets every 3 hours so the noisy pixel removal must be done every time it resets.

Noisy pixel removal - Results



(a) Noisy pixels removed as seen in the detector




(b) Number of noisy pixels removed


Figure: Noisy pixels removed from April to October for detector I4

- ▶ Less than 15 noisy pixels are removed every 3 hours.
- ▶ Two columns have common registry.

Noisy pixel removal - Results



(a) Noisy pixels removed as seen in the detector




(b) Number of noisy pixels removed


Figure: Noisy pixels removed from April to October for detector J4

- ▶ Less than 20 noisy pixels are removed every 3 hours.
- ▶ Two columns have common registry.

Noisy pixel removal - Results



(a) Noisy pixels detector I4




(b) Noisy pixels detector J4


Figure: Relation between noisy pixels and integrated luminosity per 3 hours

- No strong correlation with luminosity.

Noisy pixel removal - Improvement



(a) Luminosity curve with noisy pixels



(b) Luminosity curve without noisy pixels

Figure: Time history of Timepix3 cluster count for LHC fill 6677

Thermal neutrons




Figure: LiF converter effect and detector I4 region separation

- Thermal neutron fluxes were determined through the ${}^6\text{Li}(n,\alpha){}^3\text{H}$ -reaction.

The thermal neutrons fluxes in the detector can be determined using the following equation:

$$\phi_i = \frac{\frac{N_{LiF}}{A_{LiF}} - \frac{N_{Si}}{A_{Si}}}{\varepsilon} \quad (1)$$

- ▶ $\phi_i \rightarrow$ Thermal neutrons fluxes per LHC fill
- ▶ $N_{LiF} \rightarrow$ Number of heavy blobs found in the LiF region
- ▶ $N_{Si} \rightarrow$ Number of heavy blobs found in the silicon region
- ▶ $A_{LiF} \rightarrow$ LiF region (upper left side of the detector)
- ▶ $A_{Si} \rightarrow$ Silicon region (lower left side of the detector)
- ▶ $\varepsilon \rightarrow$ detector efficiency (1%)

Thermal neutrons





Figure: Influence of thermal neutrons to the signal


- Activation is not seen in the thermal neutron signal.

From clusters to luminosity

From clusters to luminosity



(a) Clusters detector I4



(b) Cluster detector J4

Figure: Relation between clusters and luminosity per fill

Remarks:

- ▶ Due to failures of the control PC data of some fills were not complete (these were removed from the analysis).
- ▶ Special physics fills are not considered.

From clusters to luminosity




Figure: Relation between thermal neutrons and integrated luminosity per fill

Remarks:

- ▶ Due to failures of the control PC data of some fills were not complete (these were removed from the analysis).
- ▶ Special physics fills are not considered.

Luminosity curve

The bunch population N evolution is described by

$$-\frac{dN}{dt} = \lambda_{bb} \frac{N^2}{N_0} + \lambda_g N$$


with N_0 = Initial Population

λ_{bb} = Loss rate due to beam – beam interactions


λ_g = Loss rate due to beam – gas interactions

$$\Rightarrow N(t) = \frac{N_0 e^{-\lambda_g t}}{1 + \frac{\lambda_{bb}}{\lambda_g} (1 - e^{-\lambda_g t})}$$

Luminosity curve - Fitted luminosity curve



(a) Luminosity curve




(b) $(data - fit)/\sigma_{data}$


Figure: Fitted luminosity curve - All clusters

- The sigma value higher than 1 is due to systematic effects (activation).

Luminosity curve - Fitted luminosity curve



(a) Luminosity curve



(b) $(data - fit)/\sigma_{data}$

Figure: Fitted luminosity curve - Thermal neutrons

Conclusions

- ▶ The noisy pixel removal has been implemented and on average less than 0.1% of the pixels are removed.
- ▶ Thermal neutrons show less background signal than the other types of clusters.
- ▶ Clusters are strongly correlated to luminosity which allows us to find a normalization factor between them.
- ▶ Using thermal neutrons for the luminosity curve lowers the systematic uncertainties from the clusters count rate.

Thank you for your attention!

Catalina Lesmes Ramírez
clesmes@eafit.edu.co